

Remote controle

Activate your DOME Pendant

When you switch on the DOME Pendant, it takes up to 30 minutes before the DOME Pendant reaches its full temperature. When switched off, it may take up to 40 minutes before the DOME Pendant has completely cooled down. To activate your DOME Pendant use the remote controle as shown:

